



# FIRE DOOR CAULK®

## INSTALLATION INSTRUCTIONS

REMEDi8® Fire Door Caulk® is a product that can be used as a stand alone filler/patch solution for rated steel frames and steel and wood doors rated up to and including 1 1/2 hours.

### Installing Fire Door Caulk®:

1. Ensure hole or cutout is clean and free from debris.
2. Apply the Fire Door Caulk to fill hole to a depth between flush and within 1/8" of the face of the door. Remove excess Fire Door Caulk from the surface immediately.
3. Allow 24 hours for the Fire Door Caulk to cure.
4. The Fire Door Caulk can be sanded and stained or painted as desired for aesthetic purposes.
5. Wood filler or other cosmetic fillers, up to 1/8" in thickness, may be used.



MISCELLANEOUS FIRE DOOR ACCESSORIES  
MISCELLANEOUS FIRE DOOR ACCESSORIES,  
POSITIVE-PRESSURE TESTED

